


ENGLISH

**E-SUN Q BR
WIRING DIAGRAM**

LEGEND

U = MOTOR PHASE 1 } No
V = MOTOR PHASE 2 } POLARITY
W = MOTOR PHASE 3 }
PE = GROUND

! THE BRIDGE RECTIFIER IS NOT REQUIRED ON SLIDING OPERATORS BECAUSE IT IS ALREADY CONNECTED TO THE POWER TRANSFORMER



CONNECT TO THE SWITCHING OR TO THE POWER SUPPLY